

SPX. AUTOBOSS TECH. INC.
Autoboss Scanner Function List

Basic Function List

SEAT Can Function List

Autoboss Scanner: V30
 Version: V3.3
 Date: 2009-03-05

System	Read DTC	Clear DTC	Stream Data	Testing	basic setting	Adaptation	Security Access	Coding	CodingII	control unit versions
01-Engine	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
41-Diesel Pump	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
02-Auto Trans	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
32-Differential Locks	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
11-Engine II	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
51-Electric Drive	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
12-Clutch	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
21-Engine III	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
61-Battery Regul.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
22-AWD	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
31-Engine other	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
71-Battery Charger	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
03-ABS	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
14-Susp.Elect.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
74-Chassis	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

SPX. AUTOBOSS TECH. INC.

Autoboss Scanner Function List

42-Door	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
13-Auto	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
24-Anti	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
15-Airbags	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
52-Door	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
23-Brake	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
34-level	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
55-Xenon	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
62-Door,Rear	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
43-Brake	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
44-Steering	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
65-Tire	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
72-Door,Rear	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
53-Parking	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
54-Rear	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
58-Aux	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
78-Slide	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
04-Steering	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
64-Stabilizers	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
68-Wiper Electr	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
0D-Slide Door ,left	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
35-Centr.Locks	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
06-Seat	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

SPX. AUTOBOSS TECH. INC.

Autoboss Scanner Function List

08-Auto	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
1C-Position	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
45-Inter.Monitor	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
16-Streering	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
18-Aux.Heat	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3C-Lane	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
63-Entry	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
26-Auto	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
28-HVAC,	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4C-Tire	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
73-Entry	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
36-Seat	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
38-Roof	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
5C-Lane	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
7D-Aux.Heat	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
46-Central	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
48-Seat,Rear,DS	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
6C-Back-up	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
0B-Sec.Air	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
66-Seat,Rear	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
05-Acc/Start	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
07-Control	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
57-TV	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

SPX. AUTOBOSS TECH. INC.

Autoboss Scanner Function List

29-Left	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
25-Immobilizer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
17-Instruments	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
67-Voice	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
39-Right	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
75-Telematics	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
27-Ctrl	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
77-Telephone	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
49-Automatic	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
56-Radio	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
37-Navigation	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
09-Cent. Elect	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
59-Tow	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
76-Park	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
47-Sound	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
19-CAN	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
69-Trailer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
1D-Driver	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
0E-Media	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4E-Ctrl	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
0F-Digital	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
2D-Intercom	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

SPX. AUTOBOSS TECH. INC.

Autoboss Scanner Function List

1E-Media	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
5E-Ctrl	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
1F-Sat.Tuner	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3D-Special	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
2E-Media	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
6E-Ctrl	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
2F-Digital	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4D-Data	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3E-Media	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
7E-Ctrl	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4F-Centr.Electr.II	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
5D-Operations	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
5F-Information	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
6D-Trunk	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
6F-Centr.Conv.II	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

SPX. AUTOBOSS TECH. INC.
Autoboss Scanner Function List

Basic Function List

SEAT Without Can Function List

Autoboss Scanner: V30
 Version: V3.3
 Date: 2009-03-05

System	control unit versions	Read fault	Final control	basic setting	Erase fault	End output	Coding	Read measuring value block	Read individual measuring value	Adapt -ation	Login	Write VIN	Coding 2	Authoris -ation
01-Engine	√	√	√	√	√	√	√	√	√	√	√	√	√	√
02-Auto Trans	√	√	√	√	√	√	√	√	√	√	√		√	√
03-ABS Brakes	√	√	√	√	√	√	√	√	√	√	√		√	√
08-Auto HVAC	√	√	√	√	√	√	√	√	√	√	√		√	√
09-Cent.Elect.	√	√	√	√	√	√	√	√	√	√	√		√	√
15-Airbags	√	√	√	√	√	√	√	√	√	√	√		√	√
16-Steering wheel	√	√	√	√	√	√	√	√	√	√	√		√	√
17-Instruments	√	√	√	√	√	√	√	√	√	√	√		√	√
18-Aux.Heat	√	√	√	√	√	√	√	√	√	√	√		√	√
19-CAN Gateway	√	√	√	√	√	√	√	√	√	√	√		√	√
22-AWD	√	√	√	√	√	√	√	√	√	√	√		√	√
25-Immobilizer	√	√	√	√	√	√	√	√	√	√	√		√	√
35-Centr.Locks	√	√	√	√	√	√	√	√	√	√	√		√	√
37-Navigation	√	√	√	√	√	√	√	√	√	√	√		√	√
45-Inter.Moniter	√	√	√	√	√	√	√	√	√	√	√		√	√

SPX. AUTOBOSS TECH. INC.

Autoboss Scanner Function List

46-Central Conv.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
55-Xenon Range	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
56-Radio	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
01-Engine	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
41-Diesel Pump	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
02-Auto Trans	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
32-Differential Locks	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
11-Engine II	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
51-Electric Drive	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
12-Clutch	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
21-Engine III	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
61-Battery Regul.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
22-AWD	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
31-Engine other	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
71-Battery Charger	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
03-ABS Brakes	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
14-Susp.Elect.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
15-Airbags	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
58-Aux Fuel Tank	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
13-Auto Dist.Reg	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
24-Anti Slip	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
55-Xenon Range	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
68-Wiper Electr.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
23-Brake Booster	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

SPX. AUTOBOSS TECH. INC.

Autoboss Scanner Function List

34-Level Control	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
65-Tire Pressure	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
1C-Level Sensing	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
43-Brake assist	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
44-Steering Assist	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
53-Parking Brake	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
54-Rear Spoiler	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
64-Stabilizers	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
35-Centr.Locks	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
06-Seat Mem.Pass	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
08-Auto HVAC	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
42-Door Elect.Driver	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
45-Inter.Monitor	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
16-Steering wheel	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
18-Aux.Heat	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
52-Door Elect.Pass.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
63-Entry Assist.D	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
26-Auto Roof	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
28-HVAC,Rear	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
62-Door,Rear Right	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
73-Entry Assist,P	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
36-Seat Mem.Drvr	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
38-Roof Electronics	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
72-Door,Rear Right	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

SPX. AUTOBOSS TECH. INC.

Autoboss Scanner Function List

7D-Aux.Heat	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
46-Central Conv.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
48-Seat,Rear,DS	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
78-Slide Door,Right	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
66-Sear,Rear PS	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
0D-Slide Door,Left	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
05-Acc/Start Auth	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
17-Instruments	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
57-TV Tuner	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
29-Left Light	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
25-Immobilizer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
27-Ctrl Head,Rear	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
67-Voice Control	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
39-Right Light	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
75-Telematics	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
37-Navigation	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
77-Telephone	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
49-Automatic Light	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
56-Radio	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
47-Sound System	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
09-Cent.Elect.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
59-Tow portection	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
76-Park Assist	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
19-CAN Gateway	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
69-Trailer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

SPX. AUTOBOSS TECH. INC.

Autoboss Scanner Function List

07-Control Head	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
1D-Driver Ident.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
0E-Media Player 1	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4E-Ctrl Head RR	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
0F-Digital Radio	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
2D-Intercom	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
1E-Media Player 2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
5E-Ctrl Head Roof	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
2F-Digital TV	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3D-Special Function	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
2E-Media Player 3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
6E-Ctrl Head Roof	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
2F-Digital TV	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4D-Data Transfer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3E-Media Player 4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
7E-Ctrl Head Dash	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4F-Centr.Electr.II	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

Special Function List

SEAT Function List

Autoboss Scanner: V30
Version: V3.3
Date: 2009-03-05

Function	Description
Instrument reset service	Instrument reset service
SRS reset service	VW3+VW5+VW6
Read PIN(II IMMO from Immobilizer box)	Santana 2000/3000
Read PIN(II IMMO from Instrument)	Passat 1.8GSi etc.
Read PIN(III IMMO from Engine)	Passat 1.8T,Bora 1.8T,SEAT A6 2.8 etc.
Odometer read and write	Passat 1.8 GSi etc.