

OBDII V2.8 Function List

Protocol	Functions
ISO	1,2,3,4,5,6,7,8,9,10
KWP	1,2,3,4,5,6,7,8,9,10
VPW	1,2,3,4,5,6,7,8,9,10
PWM	1,2,3,4,5,6,7,8,9,10
CANBUS	1,2,3,4,5,6,8,10

Remark:

1. Read Current Trouble Code
2. Clear Trouble Code
3. Read Current Data
4. Read Pending Trouble Code
5. Read Freeze Frame Data
6. Readiness Tests
7. Oxygen Sensor Test Results
8. On-Board Monitoring Test
9. Read System Information
10. Unit Conversion